

PHYSICS PRACTICAL SHEETS

Date 10th Oct 2023

KU CAMPUS

Class CE

Experiment No. 3

Roll No. 25

Group T

Shift Afternoon

Sub. PHY102

Object of the Experiment (Block Letter)

Set

DETERMINATION OF SURFACE TENSION OF WATER BY CAPILLARY RISE METHOD

Apparatus Required:

- i) Capillary tube, uniform bore and different radii
- ii) Needle
- iii) A glass strip
- iv) Thin rubber band
- v) Glass vessel
- vi) clamp stand
- vii) Travelling microscope
- viii) Adjustable stand

Theory

When a capillary tube is dipped in water, it rises in the capillary tube till the weight is balanced by the upward component of the surface tension. At equilibrium, the weight of the liquid column and the vertical component of the surface tension are equal. So,

$$2r\pi\cos\theta = \pi r^2\left(h + \frac{r}{3}\right)\rho g$$

Here,

r = radius of tube

h = height of liquid column.

ρ = density of water column

γ = surface tension of water.

Since $r \ll h$ and $\theta \approx 8-9^\circ$, Then the surface tension of the liquid is determined by formula

$$\gamma = \frac{r h \rho g}{2}$$

Observations and Calculations


Temperature of water (T) = 25°C

Least count of vernier scale = $1/20$ cm

No. of vernier divisions = 50

Vernier constant = 0.001 cm

Density of water = 1 gm/cc



Experimental arrangement for measuring surface tension.




Fig. Cross-section of capillary tube.

Tube No	Position of meniscus	Position of needle tip	Height
No of obs	Values of Main scale Vernier scale	Values of Main scale Vernier scale	$h = X - Y$
	Total X (cm)	Total Y (cm)	(cm)
I			
1	4.7031	2.520	2.180
2	4.705	2.525	
II			
1	4.703	2.520	2.184
2	4.711	2.525	

Determining diameter of the capillary tube.

No of obs	Tube No	Microscope reading	Diameter	Mean diameter	Mean radius
		a b c d	b-a d-c		
1	I	6.040 5.914 7.976 7.846	0.126 0.130	0.128	0.064
2	II	6.087 5.944 7.867 7.722	0.143 0.145	0.144	0.072

#Result

The value of surface tension for
 tube I. $\gamma = 68.3148$
 tube II. $\gamma = 77.05152$

The mean value of surface tension of water = $72.70816 \text{ dyne cm}^{-1}$.

The surface tension of water ($T = 25^\circ\text{C}$) = $70.4 \text{ dyne cm}^{-1}$.

$$\therefore \% \text{ error} = \left| \frac{72.70816 - 70.4}{70.4} \right| \times 100\% = 3.27\%$$